




Axelent X-Guard Assembly Guide D26-XXX140



20130812

 B26-5K x 1	 x 2 A	
B26-5J x 1	 x 4 A x 4 B x 4 C x 4 D x 8 E x 4 F	B20-2C x 1 x 1 A

