






















Axelent X-Guard Assembly Guide D30-XXX1 50B



- BG Инструкции за монтаж
- CZ Montážní návod
- DE Montageanleitung
- DK Monteringsvejledning
- EE Paigaldusjuhised
- ES Instrucciones de montaje
- FI Kokoamisohje
- FR Les instructions d'assemblage
- GB Assembly instructions
- GR οδηγίες συναρμολόγησης
- HU Összeszerelési utasítások
- IE Treoracha cóimeála
- IT Istruzioni di montaggio
- LT Surinkimo instrukcija
- LV Montāžas instrukcijas
- MT Assemblaġġ istruzzjonijiet
- NL Montagehandleiding
- PL Instrukcja montażu
- PT Instruções de montagem
- RO Instrucțiunile de asamblare
- SE Monteringsanvisning
- SI Setavljanje navodila
- SK Montážny návod



Axelent AB
Box 1 · Kävsjövägen 17
SE-330 33 Hillerstorp
Axelent Direct. 0370-37 37 37
Fax. 0370-37 37 47
E-mail. sales@axelent.se
Internet. www.axelent.se

| | | | | | | | | | | | |
|--|--|--|--|--|---|--|--|--|--|--|--|
|  D3K-1630 x 1 |  x 1 A |  B10-1C x 2 |  x 2 A |  x 2 B |  B00-010 x 1 |  x 2 A |  x 8 B | 20160411 | | | |
|  B30-1A x 1 |  x 2 A |  x 4 B |  x 2 C |  x 2 D |  x 4 E |  x 4 F |  x 2 G |  B10-1B x 2 |  x 2 A |  x 2 B |  x 2 C |

AXELENT X-GUARD D30-XXX150B

